






Wiring Diagram for Parallel to Serial Converter (with Printer)






Wiring Diagram for Parallel to Serial Converter (w/o Printer)



OR




Cabling Details of Parallel to Serial Converter




DB-25 to C-36 Cable Wiring Diagram (Standard)

SXP-325A (DB25-Female)




T-Cable (DB-25) Wiring Diagram (Custom)





Serial Cable Wiring Diagram (DB-25/M to DB-9/F and TOV)

Wiring Diagram for TOV-340 Serial Port



Serial Port Configuration
 Baud Rate = 9600
 Stop Bit = 1
 Parity = None
 Flow Control = None
 FIFO = Not important



Serial Port Configuration
 Baud Rate = 9600
 Stop Bit = 1
 Parity = None
 Flow Control = XON/XOFF
 FIFO = Disable

